

Installation



DD WOOD
ไม้บัวดีดงู

End Skirting cornice

Caution: Avoid solvents base as thinner. Cause wood pattern may be damaged.



1
Put the end skirting-cornice on the end of wall. Measure the length space between the end skirting-cornice with skirting cornice as shown as picture.



2
Cut off the cornice length that we get from the 1st method. Use hot glue to stick the end skirting-cornice with skirting cornice as shown as picture.



3
Put the power nail glue and install the skirting cornice.



4
After finishing as shown as the picture.